Special Notice - MP-E Editor/Assembler Cassette Tapes

The editor and assembler programs for your SWTPC 6800 Computer System have been supplied on separate tapes. Each tape has either the editor or assembler recorded on both sides. Side 1 is the side normally used - side 2 has a much longer leader that was necessary when duplicating the tapes. As soon as you receive your tapes duplicate them immediately. When punching a copy of the editor set up the start punch at Ø1ØØ and stop at ØB5F. The assembler goes from ØØ8Ø to 17FF. Both programs should be initiated with the program counter set at Ø1ØØ.

NOTE: When using the assembler with a PR-40 printer, the print command should be given immediately before the pass command. For a printer in the #5 slot for example, the correct command after "ENTER PASS" for the second pass would be P52P.